


Installation Manual

Adjustable Ground Mounting System





TRIPSOLAR


www.tripsolar.com

Solar Bracket Solar System Manufacture


Folding U-shaped bracket




End Clamp




Inter Clamp




Plate




Screw




Step1. Arrange the folding brackets with same angle at equal intervals.




Step2. Place the panels between two brackets as shown in the picture.



Step3. Confirm the adjusted angle and lock the screws.



Step4. Lock the Inter Clamps and End Clamps into the rivet nut.



Step5. Put the ballast plate in right position and place a heavy objects on the ballast plate. Finsh.

